

Instruments

Speedometer

i-Multi-Information Display

➔ P.21


Tachometer

NOTICE

Do not operate the engine in the tachometer red zone. Excessive engine speed can adversely affect engine life.

Tachometer red zone

(excessive engine rpm range)



SELECT ▲ (up) button

SELECT ▼ (down) button

SET button

Display Check

When the ignition switch is turned on, the opening symbol will show on the i-multi-information display. If the display does not show when it should, have your dealer check for problems.