


Audio System *(Continued)*

Audio System Location



i-Multi-Information Display ➔ P. 49

Speakers

TRACK button
Changes tracks.

VOLUME button
Adjusts the volume. This button is also used to pair the *Bluetooth*® devices. ➔ P. 51

MUTE button
Mutes the audio. This button also is used to select the SVC mode. ➔ P. 60

MODE button
Selects the audio mode. This button is also used to pair the *Bluetooth*® devices. ➔ P. 51

USB connector
➔ P. 55

AUDIO power button
Switches the audio system on/off. This button is also used to activate/deactivate automatic mute. ➔ P. 59