

TCS (Traction Control System) Indicator

If the indicator operates in one of the following ways, you may have a serious problem with the TCS (Traction Control System). Reduce your speed and have your motorcycle inspected by your dealer as soon as possible.

- Indicator comes on while riding.
- Indicator does not come on when the ignition switch is turned on.
- Indicator does not go off at speeds above 10 km/h (6 mph).

Even when the TCS indicator is on, your motorcycle will have normal riding ability without TCS function.

- When the indicator comes on while the TCS is in operation, you will have to close the throttle grip completely to regain normal riding ability.

The TCS indicator may come on if you turn the rear wheel while your motorcycle is lifted off the ground. In this case, turn the ignition switch off and then on again. The TCS indicator will go off after your speed reaches 10 km/h (6 mph).