


COLOUR LABEL

The colour label (1) is attached below the right side of the head pipe.

It is helpful when ordering replacement parts. Record the colour and code here for your reference.

COLOUR _____

CODE _____



(1) Colour label