

Replace tires before tread depth at the center of the tire reaches the following limit.

| Minimum tread depth | |
|---------------------|-------------------|
| Front: | 1.5 mm (1/16 in.) |
| Rear: | 2.0 mm (3/32 in.) |

Repair/Replacement:

See your authorized Honda Dealer.

WARNING

- * *The use of tires other than those listed on the tire information label may adversely affect handling.*
- * *Do not install tube-type tires on tubeless rims. The beads may not seat and the tires could slip on the rims, causing tire deflation.*
- * *Proper wheel balance is necessary for safe, stable handling of the motorcycle. Do not remove or change any*

wheel balance weights. When wheel balancing is required, see your authorized Honda dealer. Wheel balancing is required after tire repair or replacement.

- * *Do not ride at high speeds for the first 24 hours after tire repair, or failure of the repair material and tire deflation may result.*

CAUTION

- * *If the tire sidewall is punctured or damaged, the tire must be replaced.*
- * *Do not try to remove tubeless tires without special tools and rim protectors. You may damage the rim sealing surface or disfigure the rim.*