

Fuel Gauge

The fuel gauge (1) shows the approximate fuel supply available. At F(full) there is 19 liters (5.0 U.S. gal., 4.2 Imp. gal.). When the gauge needle first points to RES there is about 2.5 liters (0.66 U.S. gal., 0.55 Imp. gal.) left in the tank.

When the gauge points to RES, refill the tank as soon as possible.

CAUTION: This motorcycle requires low-lead gasoline with an Octane number of 91 or higher.



Indicador de nivel de combustible

El indicador de nivel de combustible muestra la cantidad aproximada del combustible disponible. Cuando indica la aguja el valor F (pleno), hay 19 litros de combustible en el tanque, incluyendo el de suministro en reserva. Cuando la aguja del indicador quela, primero, en la zona RES, significa que existe todavía unos 2,5 litros de gasolina en le tamque.

Cuando el indicador señale la zona RES, llenar el tanque pronto como sea posible.

PRECAUTION: Esta motocicleta requerir gasolina de bajo contenido de plomo con un el indice octáncio de 91 o superion.