

CONTENTS

	Page
SAFE DRIVING PRECAUTIONS	7
SERIAL NUMBER LOCATIONS	13
CONTROL LOCATIONS	14
CONTROL FUNCTION	15
* Choke lever	15
* Throttle lever	16
* Brake lever and Parking brake	17
* Engine stop (Emergency) switch	18
* Lighting switch	19
* Seat position adjustment	20
* Seat belt	21
* Recoil starter	23
* Fuel filler cap	23
* Tool kit	24
* Emergency starter	25
FUEL AND OIL	26
* Mixing procedures	27
* Refueling	28
PRE-DRIVING INSPECTION	30
STARTING THE ENGINE	32
* Normal starting procedures	32
* Restarting the engine after running out of fuel	36
* Emergency starting procedures	38
BREAK-IN PROCEDURE	40
DRIVING	41