

Lighting switch

The lighting switch ① has three positions, "OFF", "LO" and "HI".

OFF : Headlight and taillight are off.

LO : Headlight low beam and taillight are on.

HI : Headlight high beam and taillight are on.

NOTE:

The lights will not operate unless the engine is running.

Commande d'éclairage

La commande d'éclairage ① comporte trois positions, "OFF" (hors-circuit) "LO" (code) et "HI" (phare).

OFF : Le phare et la lanterne arrière sont éteints.

LO : Le code et la lanterne arrière sont allumés.

HI : Le feu de route et la lanterne arrière sont allumés.

REMARQUE:

L'éclairage n'est obtenu que lorsque le moteur est mis en marche.

