

Seat Position Adjustment

Adjust the seat back position by pulling the adjusting lever ② up. The adjustable travel is 140mm (5.5 in).

For the best seat positioning, adjust the seat so that your legs are slightly bent when resting your feet on the floor step board.

WARNING

Do not adjust the seat back while the ODYSSEY is in motion, the seat back could move suddenly, causing loss of control.

Réglage du siège

Régler la position du dossier du siège en tirant le levier de réglage vers le haut ②. Le jeu de réglage est de 140mm (5.5po).

Pour obtenir la position idéale du siège, régler de façon à ce que vos jambes soient légèrement fléchies en reposant vos pieds sur la planche de fond.

AVERTISSEMENT

Ne pas régler le dossier du siège lorsque l'ODYSSEY est en marche, car le dossier pourrait se déplacer soudainement causant ainsi une perte de contrôle.

