

3. Remove the fuel tank cap and check to see that the fuel is returning from the fuel return pipe ① while cranking the engine by pulling the starter rope ②. If the fuel is returning, the carburetor float chamber is filled with fuel. Replace the fuel tank cap securely.
4. Refit the spark plug, pull the starter rope with the choke lever down and start the engine.

3. Enlever le bouchon du réservoir d'essence et vérifier si l'essence retourne de la canalisation de renvoi de l'essence ① pendant que vous lancez le moteur à l'aide du câble de démarrage ②. Si l'essence retourne, la cuve à niveau constant du carburateur est remplie d'essence. Replacer fermement le bouchon du réservoir.
4. Reposer la bougie, tirer le câble de démarrage avec le levier du volet d'air abaissé et faire démarrer le moteur.

