

STORAGE ENTREPOSAGE

Preparing the ODYSSEY for storage

1. Completely clean all parts of the ODYSSEY. When exposed to foul water, sea breeze or salt water, wash the ODYSSEY down with fresh water and wipe dry.
2. Drain fuel from the fuel tank and carburetor.
3. Wax all body parts and lubricate all mechanical components.
4. Store in a place which is free from humidity and dust.
5. Inflate tires to normal pressure and place the ODYSSEY on suitable blocks to raise the tires off the ground.

Préparation de l'ODYSSEY pour l'entreposage

1. Nettoyer à fond toutes les pièces de l'ODYSSEY. Si elle est exposée au vent de mer ou à l'eau salée, la laver entièrement avec de l'eau fraîche et l'assécher.
2. Vidanger l'essence du réservoir d'essence et du carburateur.
3. Cirer toutes les pièces de carrosserie et lubrifier toutes les pièces mécaniques.
4. Entreposer dans un endroit à l'abri de l'humidité ou de la poussière.
5. Gonfler les pneus à la pression normale et placer l'ODYSSEY sur les blocs appropriés afin de soulever les pneus du sol.