


Kick Starter Pedal

In the event your battery is run down so that the engine cannot be started by the electric starter, use the kick starter pedal. Open the right access panel and take out the pedal. Remove the rubber cap 2 from the kick starter socket at the rear of the engine and insert the pedal in the socket all the way. Ensure that the transmission is in the neutral position. Place the motorcycle on the center stand. While standing next to the motorcycle, kick the pedal rapidly from the top down. After the engine


starts, remove the starter pedal from the starter socket and place it in the right side compartment.

WARNING:

- *Be sure that the kick starter pedal engages fully in the kick starter socket.*
 - *Do not attempt to start the engine with the kick starter while astride the motorcycle. Injury could result if your foot slips off the pedal.*
 - *Do not allow the kick starter snap back freely against the pedal stop.*
-



① Kick starter pedal



② Rubber cap

