International Internation of the Internation of the Internation of the International Internation of the International Internatio

The mileage intervals shown in the MAINTENANCE SCHEDULE are intended as a guide for establishing regular maintenance and lubrication periods for your Honda. Sustained severe or high speed operation under adverse conditions necessitates more frequent servicing. To determine specific recommendations for conditions under which you use your motorcycle, consult your authorized Honda dealer. If your GL 1000 is ever overturned or involved in a collision, have your Honda dealer

carefully inspect the major components, e.g. frame, suspension and steering parts, for misalignment or damage to ensure further safe operation.

WARNING: To maintain the safety and reliability of your HONDA motorcycle do not modify the motorcycle and use only genuine HONDA parts when servicing or repairing.

The use of other replacement parts which are not of equivalent quality may impair the operation of your motorcycle.