

6. Do not exceed maximum capacity load of Honda accessories.

Travel trunk:	9 kg (20 lbs)
Saddlebags:	9 kg (20 lbs) each side
Fairing pockets:	2 kg (5 lbs) each side
Trunk side pockets:	0.5 kg (1 lbs) each side
7. Honda fairing, travel trunk and saddlebags are designed for GL1100, GL1100DX, GL1100DX-II and GL1100 ASPENCADE only. Do not install them on any other motorcycle.
8. Do not store articles between fairing and motorcycle. They may interfere with steering causing loss of control.
9. Do not remove the weight attached to the front forks near the steering head when the fairing is installed. Stability may be adversely affected.

-
6. No exceda la capacidad máxima de carga de los accesorios Honda.

Portaequipajes para viaje:	9 kg (20 lbs)
Alforjas:	9 kg (20 lbs) en cada lado
Bolsas:	2 kg (5 lbs) en cada lado
Bolsillos laterales del portaequipajes:	0.5 kg (1 lbs) en cada lado
 7. El carenado, portaequipajes y las alforjas están diseñadas solamente para los modelos GL 1100, GL1100DX, GL1100DX-II y GL1100 ASPENCADE. No les instale en otros tipos de motocicletas.
 8. No poner artículos entre las bolsas y la motocicleta. Podrían interferir la dirección causando la pérdida del control.
 9. No extraiga el contrapeso instalado en las horquillas frontales cerca de la cabeza de dirección cuando se instalen las bolsas. Podría afectarse adversamente la estabilidad.