


## Carburetor Adjustment

1. Start and warm up the engine to normal operating temperature.
2. Set the engine idle speed to  $950 \text{ min}^{-1}$  (rpm) by adjusting the stop screw (1). Turning the stop screw in the (A) direction will increase the rpm, and turning in the (B) direction will result in a decrease.



---

## Ajuste del carburador

1. Arranque y caliente el motor hasta llegar a la temperatura normal de funcionamiento.
2. Ajuste la velocidad del motor de marcha en vacío a  $950 \text{ min}^{-1}$  (rpm), mediante el tornillo de tope (1). Haga girar el tornillo de tope en la dirección de (A), y la velocidad del motor será aumentada; y en la dirección de (B), reducida.