

| ITEM | FREQUENCY | NOTE | ODOMETER READING [NOTE (1)] | | | | | | | | Refer to page | |
|----------------------------------|---------------------------|----------|-----------------------------|-----|-----|------|------|------|------|------|------------------|--------|
| | | | × 1,000 mi | 0.6 | 4 | 8 | 12 | 16 | 20 | 24 | | |
| | | | × 1,000 km | 1 | 6.4 | 12.8 | 19.2 | 25.6 | 32.0 | 38.4 | | |
| NON-EMISSION RELATED ITEMS | FINAL DRIVE OIL | | | | I | | | I | | | R | 28, 79 |
| | BRAKE FLUID | NOTE (4) | | | I | I | R | I | I | | R | 18 |
| | BRAKE PAD WEAR | | | | I | I | I | I | I | | I | 80 |
| | BRAKE SYSTEM | | | I | | I | | I | | | I | 18, 80 |
| | * BRAKE LIGHT SWITCH | | | | | I | | I | | | I | — |
| | * HEADLIGHT AIM | | | | | I | | I | | | I | — |
| | CLUTCH SYSTEM | | | | | I | | I | | | I | — |
| | CLUTCH FLUID | NOTE (4) | | | I | I | R | I | I | | R | 20 |
| | SIDE STAND | | | | | I | | I | | | I | 82 |
| | * SUSPENSION | | | | | I | | I | | | I | — |
| | * NUTS, BOLTS, FASTENERS | | | | I | | I | | I | | I | — |
| | ** WHEELS /TIRES | | | | | I | | I | | | I | — |
| | ** STEERING HEAD BEARINGS | | | | I | | I | | I | | I | — |