

5. Remove the rear fender (18).
 - 1) Remove the mount bolts (19).
 - 2) Disconnect the stoplight and rear turn signal light connector (20).
6. Remove the rear brake bracket bolt (21).
7. Remove the axle nut (22) while holding the axle shaft (23) at the end with a wrench.
8. Pull out the axle shaft.
9. Remove the rear brake bracket (24).
10. Move the wheel to the left to separate it from the final drive gear case. Remove the rear wheel (25).

- (18) Rear fender
- (19) Mount bolts
- (20) Connector
- (21) Rear brake mount bolt
- (22) Axle nut
- (23) Axle shaft
- (24) Rear brake bracket
- (25) Rear wheel

