

BATTERY

Refer to the Safety Precautions on page 60 .

It is not necessary to check the battery electrolyte level or add distilled water as the battery is a maintenance-free (sealed) type. If your battery seems weak and/or is leaking electrolyte (causing hard starting or other electrical troubles), contact your authorized Honda dealer.

NOTICE

Your battery is a maintenance free type and can be permanently damaged if the cap strip is removed.