

---

### To Change the Set Speed:

For a faster speed with a gradual acceleration: Push and hold the RESUME/ACCEL switch until you reach the desired speed; release the switch and the system's memory will be reprogrammed to the new speed. For faster acceleration: Operate the throttle grip until you reach the desired speed, then push and release the SET/DECEL switch to re-program the system.

Any speed above 161 km/h (100 mph) will be memorized as 161 km/h (100 mph).

To change to a slower speed: Push and hold the SET/DECEL switch and the motorcycle will slow down; when you reach the desired slower speed, release the switch and the system will be reprogrammed. For temporary acceleration above the set speed, such as for passing, use the throttle conventionally. When you want to return to the set speed, close the throttle and coast without applying the brakes.

With the Cruise Control on, your speed will still vary slightly, particularly going up or down hills.