


FEATURES

(Not required for operation)


Audio System for U type

Controls Location:

LEFT HANDLEBAR CONTROLS



AUDIO CONTROLS BUTTONS



The CB and CD levers and buttons function when the Honda accessory CB radio and/or CD changer installed. For CB and CD operating instructions, refer to the accessory manuals.