




IMMOBILIZER SYSTEM (HISS)

HISS is the abbreviation of Honda Ignition Security System.




The immobilizer system (HISS) protects your motorcycle from theft. A properly-coded key must be used in the ignition switch for the engine to start. If an improperly-coded key (or other device) is used the engine's starting circuit is disabled.

When the ignition switch is turned ON and the engine stop switch is at “” (RUN), the immobilizer system (HISS) indicator lights for a few seconds, then goes off. If the indicator remains on, it means the system does not recognize the coding of the key. Turn the ignition switch to OFF, remove the key, reinsert and turn the switch ON again.

When the ignition switch is turned OFF, the immobilizer system (HISS) indicator continues to flash every 2 seconds during 24 hours. After this period, the indicator automatically switches off.

To operate this function, proceed as follows:

1. Turn the ignition switch ON or ACC.
2. Push the SETUP button and push the DIM button. Push the INFO or TRIP button to select ON or OFF. Be sure to push the SETUP button to enter your setting in the system.
3. Turn the ignition switch OFF.



Immobilizer system (HISS) indicator

