

TIRE RECOMMENDATION	23
PRECAUTIONS BEFORE RIDING	24
STARTING THE ENGINE	24
Starting a Cold Engine	24
Starting a Warm Engine	26
BREAK-IN PROCEDURE	26
RIDING THE MOTORCYCLE	27
PARKING	28
TOOL KIT	29
MAINTENANCE SCHEDULE	30
MAINTENANCE OPERATIONS	33
Engine Oil Level.....	33
Transmission Oil Level	34
Transmission Oil Change	35
Spark Plug Replacement and Adjustment	36
Ignition Timing Adjustment.....	38
Air Cleaner Maintenance	39
Carburetor Adjustment	41
Throttle Grip Adjustment.....	42
Oil Pump Cable Adjustment	43