

<b>MAINTENANCE SCHEDULE</b> This maintenance schedule is based upon average riding conditions. Machines subjected to severe use, or ridden in unusually dusty areas, require more frequent servicing.	<b>INITIAL SERVICE PERIOD</b>	<b>REGULAR SERVICE PERIOD</b> Perform at every indicated month or mileage interval, whichever occurs first.			
		Month	—	6	12
		Mile	500	3,000	6,000
		Km	1,000	5,000	10,000
DRIVE CHAIN—Check, lubricate, and adjust if necessary.	**●	○			
*BRAKE SHOES—Inspect, and replace if worn.			○		
BRAKE CONTROL LINKAGE—Check linkage, and adjust free play if necessary.	●	○			
*WHEEL RIMS AND SPOKES—Check. Tighten spokes and true wheels, if necessary.	●	○			
TIRES—Inspect.			○		
FRONT FORK OIL—Drain and refill.	●		○		
REAR FORK BUSHING—Grease. Check for excessive looseness.		○			
*STEERING HEAD BEARINGS—Adjust.			○		
BATTERY—Check electrolyte level, and add water if necessary.	●	○			
ALL NUTS, BOLTS, AND OTHER FASTENERS— Check security and tighten if necessary.	●	○			

\*\* Initial service period 200 miles.