

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓	ODOMETER READING [NOTE 3]				Refer to
			1,000 km (600 mi)	6,000 km (3,600 mi)	12,000 km (7,200 mi)	18,000 km (10,800 mi)	
DRIVE CHAIN		NOTE 2	I, L EVERY 1,000 km (600 mi)				Pages 68—72
BATTERY		MONTH	I	I	I	I	Pages 75—76
BRAKE FLUID (FRONT)		MONTH I 2 YEARS *R	I	I	I	*R	Page 62
BRAKE SHOE/PAD WEAR				I	I	I	Pages 64—65
BRAKE SYSTEM			I	I	I	I	
* BRAKE LIGHT SWITCH			I	I	I	I	
* HEAD LIGHT AIM			I	I	I	I	
CLUTCH			I	I	I	I	Pages 60—61
SIDE STAND				I	I	I	Page 73
* SUSPENSION			I	I	I	I	
* NUTS, BOLTS, FASTENERS			I	I	I	I	
** WHEELS			I	I	I	I	
** STEERING HEAD BEARING			I	I	I	I	
** COMBUSTION CHAMBER & MUFFLER DECARBONIZATION					C		

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER

* SHOULD BE SERVICED BY AN AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS THE PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SHOP MANUAL.

NOTES: 1. Service more frequently when riding in dusty areas.

2. Service more frequently when riding in rain, or at full throttle.

3. For higher odometer reading, repeat at the frequency interval established here.