
BRAKE SHOE WEAR

(Refer to the maintenance precautions on page 47).

Wear Indicator

When the brake is applied, an arrow (1) attached to the brake arm moves toward a reference mark (3) on the brake panel.

If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced.



(1) Reference mark

(2) Arrow

NOTE:


* When the brake service is necessary, see your authorized Honda dealer, who has been properly trained to perform such service. Use only genuine Honda parts or its equivalent.

Other Checks

Check the brake cable for kinks or signs of wear that could cause sticking or failure.

Lubricate the brake cable with a commercially available cable lubricant to prevent premature wear and corrosion.

Make sure the brake arm, spring and fasteners are in good condition.



(1) Reference mark

(2) Arrow