
BODY COVER SKIRT

Removal:

- 1. Remove the screws (1).
- 2. Remove the body cover skirt (2) by releasing the tabs (3).

Installation:

• Installation can be done in the reverse order of removal.



- (1) Screws
- (2) Body cover skirt

(3) Tabs