

(Ref.No.) Description	Function
(8) High beam indicator (blue)	Lights when the headlight is on high beam.
(9) Tachometer	Shows engine revolutions per minute. The tachometer needle will swing to the maximum scale on the dial once when the ignition switch is turned ON.
(10) Right turn signal indicator (green)	Flashes when the right turn signal operates.
(11) Coolant temperature gauge	Shows coolant temperature (page 38). The coolant temperature gauge needle will swing to the maximum scale on the dial once when the ignition switch is turned ON.