

<b>(Ref.No.) Description</b>	<b>Function</b>
(14) S mode indicator (amber) (NSS250A)	Lights when the S mode is selected in the automatic shift mode (page 93 ).
(15) D mode indicator (green) (NSS250A)	Lights when the D mode is selected in the automatic shift mode (page 93 ).
(16) RESET button	This button is used to reset the tripmeter to zero (0) (page 31 ). This button is also used to reset the oil change indicator (page 35 ) and adjust the time (page 32 ).