

- If you leave your scooter with the ignition switch in the OFF position, the steering cannot be locked.
- If the ignition switch is in ON position, the ignition switch cannot be locked.
- If the battery is low or there are strong radio waves or noise, the operating range will be restricted or the system may not be activated.
- If any operation is not completed within 20 seconds after pushing the ignition switch in, the Honda smart card key indicator will go off and lock the ignition switch after the ignition switch illumination and all turn signals flash twice.
- Approximately 20 seconds after turning the ignition switch to OFF or LOCK from ON, the Honda smart card key indicator goes off, and the ignition switch illumination and all turn signals flash twice. Then the ignition switch will be locked.
- If the Honda smart card key is OFF, the Honda smart card key system cannot be activated even within the operating range.