


## Mode Shift Switch (NSS250A)

To shift between the automatic shift mode and 7-speed automatic mode, press the mode shift switch (3).

This switch is also used to change the 7-speed manual mode to 7-speed automatic mode.



(3) Mode shift switch