


Switching 7-speed Manual Mode to 7-speed Automatic Mode:

Press the mode shift switch (1) once. The “A” icon mark (2) appears on the shift information display (3).

- You cannot change 7-speed manual mode to automatic shift mode directly.
- If you press and hold the mode switch, the sequential mode switching can not be done.



- (1) Mode shift switch
- (2) “A” icon mark
- (3) Shift information display