


Shifting When the 7-speed Manual Mode Is Selected

Press the shift switch to shift gears when the 7-speed manual mode is selected. The shift indicator (1) shows the gear position on the shift information display (2).

When the 7-speed manual mode is selected, shifting is not automatic. Shift so as not to let the engine rev enter the red zone.

To upshift transmission, press the shift switch (+) (3) once.

To downshift transmission, press the shift switch (-) (4) once.



- (1) Shift indicator
- (2) Shift information display
- (3) Shift switch (+)
- (4) Shift switch (-)