


Shifting Restriction:

If the system determines that the travel device will be damaged or there will be over revving of the engine while shifting, the shift indicator (1) flashes and shifting can not be done.

- If you have any trouble shifting or hear a noise, see your Honda dealer.
- When riding on a slippery road, shifting down may cause slip.



(1) Shift indicator