

MAINTENANCE SCHEDULE

The following items require some mechanical knowledge. Certain items (particularly those marked * and **) may require more technical information and tools. Consult your authorized Honda Dealer. Perform the Pre-ride Inspection at each scheduled maintenance period.

I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY

C: CLEAN R: REPLACE A: ADJUST L: LUBRICATE

ITEM	FREQUENCY	WHICHEVER COMES FIRST ↓ NOTE	ODOMETER READING [NOTE (1)]								REFER TO PAGE
			x 1,000 km	1	6	12	18	24	30	36	
			x 1,000 mi	0.6	4	8	12	16	20	24	
		MONTH		6	12	18	24	30	36		
* FUEL LINE					I		I		I	—	
* THROTTLE OPERATION					I		I		I	64	
* CARBURETOR CHOKE					I		I		I	—	
* AIR CLEANER	(NOTE 2)						R		R	—	
CRANKCASE BREATHER	(NOTE 3)				C	C	C	C	C	61	
SPARK PLUG					I	R	I	R	I	61-62	
ENGINE OIL				R		R		R		57-60	
ENGINE OIL FILTER				R		R		R		58-60	
* CARBURETOR SYNCHRONIZATION				I		I		I		—	
* CARBURTOR IDLE SPEED				I	I	I	I	I	I	64	
RADIATOR COOLANT	(NOTE 4)					I		I		R 21-22	
* COOLING SYSTEM						I		I		—	
* SECONDARY AIR SUPPLY SYSTEM	(NOTE 5)					I		I		—	