

**▲ WARNING**

- \* **Do not attempt to patch a damaged tyre or inner tube. Wheel balance and tyre reliability may be impaired.**
- \* **Improper tyre inflation will cause abnormal tread wear and create a safety hazard. Underinflation may result in the tyre slipping on, or coming off of the rims, causing tyre deflation that may result in a loss of vehicle control.**
- \* **Operation with excessively worn tyre is hazardous and will adversely affect traction and handling.**
- \* **The use of tyres other than those listed on the tyre information label may adversely affect handling.**
- \* **Maintenance of spoke tension and wheel trueness are critical to safe motorcycle operation. During the first 1000 km (600 miles) spokes will loosen more rapidly due to initial seating of parts. Excessively loose spokes may result in high speed instability and possible loss of control.**

Replace tyre before tread depth at the center of the tyre reaches the following limit:

Minimum tread depth	
Front:	1.5 mm (0.06 in)
Rear:	2.0 mm (0.08 in)