

# CONTENTS

---

## MAINTENANCE

Page		Page	
59	MAINTENANCE	79	FRAME/WHEELS/ BRAKES
60	Maintenance Schedule	79	Front Wheel Removal
62	Tool Kit	83	Rear Wheel Removal
63	Serial Numbers	86	Brake Wear Indicators
63	Color Label	87	Side Stand
64	Maintenance Precau- tions	88	ELECTRICAL
65	Cover Removal	88	Battery
70	FILTERS/LUBRICATION	90	Fuse Replacement
70	Engine Oil And Filter	92	CLEANING
73	Air Cleaner	94	STORAGE GUIDE
75	ENGINE	94	Storage
75	Spark Plugs	95	Removal From Storage
77	Idle Speed	96	SPECIFICATIONS
78	DRIVE TRAIN	98	NOISE EMISSION (AUSTRALIA ONLY)
78	Final Drive Oil		