

3. When the oil has been completely drained, check that the drain plug sealing washer is in good condition and install the drain plug.
4. Reinstall the oil drain plug securely and fill the crankcase with approximately 1.9 ℓ (2.0 US qt) of the recommended oil.
5. Reinstall the oil filler cap.
6. Start the engine and let it idle for a few minutes.
7. Stop the engine and make sure that oil level is between the upper and lower marks on the dipstick. If necessary, add more oil but do not overfill.

CAUTION:

- **Running the engine with improper oil level can cause serious engine damage.**
- **Improper installation of the oil filter can cause serious engine damage.**

NOTE:

To protect the environment, please dispose of used engine oil properly. We suggest you place used oil in a sealed container and take it to your local service station for reclamation. Do not put it in the trash or pour it on the ground.