

Climbing hills	65
Clutch adjustment.....	103
Consumer information	139
Crossing slopes.....	74
Customer service	141

D

Dimmer switch	20
Dipstick	27, 96

E

Emission control system	139
Engine	
Idle speed adjustment.....	94
Break-in procedures	ii
Flooded engine.....	58
Starting the engine.....	55
Engine oil	
Changing oil.....	96
Checking oil level and adding oil.....	96
Oil filler cap/dipstick.....	27, 96
Recommendations	97
Engine stop switch	14
Exhaust system	
Cleaning.....	35
Purging.....	126

F

Final gear case oil	100
Flag pole bracket.....	29
Flooded engine	58
Fuel	
Fuel recommendations	86
Fuel fill cap.....	25, 84
Fuel tank capacity	84
Fuel valve.....	26
High altitude fuel mixture adjustment	95
Refueling.....	84
Reserve fuel supply.....	26
Fuse	
Location	107
Replacement.....	108