

MAINTENANCE

MAINTENANCE SCHEDULE

Perform the Pre-ride Inspection (Page 27) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace, if necessary C: Clean R: Replace A: Adjust L: Lubricate		INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
	ENGINE OIL	R	R	45
	ENGINE OIL FILTER	R	R	45
	AIR CLEANER	NOTE (1)	I	51
	SPARK PLUG		I	50
	AIR CLEANER CASE BREATHER	NOTE (2)	I	55
*	VALVE CLEARANCE	I	I	52
*	CARBURETOR IDLE SPEED	I	I	47
*	FUEL LINE	I: (EVERY YEAR)		46
*	FUEL STRAINER	C: (EVERY YEAR)		46
*	THROTTLE OPERATION	I	I	61
*	CARBURETOR CHOKE		I	-

* SHOULD BE SERVICED BY AUTHORIZED HONDA DEALER, UNLESS THE OWNER HAS PROPER TOOLS AND SERVICE DATA AND IS MECHANICALLY QUALIFIED. REFER TO THE OFFICIAL HONDA SHOP MANUAL.

** IN THE INTEREST OF SAFETY, WE RECOMMEND THESE ITEMS BE SERVICED ONLY BY AN AUTHORIZED HONDA DEALER.