


SERIAL NUMBERS

The frame and engine serial numbers are required by your dealer when ordering replacement parts. Record the numbers here for your reference.

The frame serial number (1) is stamped on the front of the frame. The engine serial number (2) is stamped on the right crankcase.

FRAME NO. _____

ENGINE NO. _____




(1) Frame serial number (2) Engine serial number

COLOR LABEL

The color label (1) is attached to the frame under the seat. It is helpful when ordering replacement parts. Record the color and code here for your reference.

COLOR _____

CODE _____



(1) Color label