

## Gearshift Pedal

The gearshift pedal is near the left footpeg. One full stroke of the gearshift pedal will shift the transmission. The pedal automatically returns to the horizontal position when released. Each stroke of the pedal engages the next gear in sequence.


Raise the pedal to upshift to a higher gear and depress the pedal to downshift.

When the reverse selector knob is pushed in and the rear brake lever is squeezed, the transmission can only be shifted from neutral to reverse gear by depressing the gearshift pedal.


### CAUTION:

\* *Bring the FOURTRAX to a complete stop before shifting the transmission into reverse. If the transmission is shifted into reverse when the vehicle is moving, damage to the transmission will result.*

Shifting sequence



UPSHIFT



DOWNSHIFT

Reverse sequence

