

## MAINTENANCE AND REPAIRS

### MAINTENANCE SCHEDULE

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean R: Replace A: Adjust L: Lubricate		EVERY	INITIAL SERVICE PERIOD (First week of operation)	REGULAR SERVICE PERIOD (Every 30 operating days)	Refer to page
*	FUEL LINE	YEAR I			—
*	FUEL STRAINER SCREEN	YEAR C			88, 89
*	THROTTLE OPERATION		I	I	90
*	CARBURETOR CHOKE			I	95
	AIR CLEANER	(NOTE 1)		C	91–93
	AIR CLEANER CASE DRAIN TUBE	(NOTE 2)		I	94
	SPARK PLUG			I	104, 105
*	VALVE CLEARANCE		I	I	105
	ENGINE OIL		R	R	28, 98–102
	ENGINE OIL FILTER		R	R	100–102
*	CARBURETOR IDLE SPEED		I	I	95–97
	FINAL DRIVE OIL	YEAR I, 2 YEARS R			103
	BRAKE FLUID	(NOTE 3)		I	117, 118