

Climbing hills	65
Clutch adjustment	106
Crossing slopes	74
Customer service	144
D	
Decompressor lever	18
Dimmer switch	20
Dipstick	28, 98
Direct current (DC) power	
Receptacle	32
Special plug	32
E	
Engine	
Idle speed adjustment	95
Break-in procedures	ii
Flooded engine	58
Starting the engine	57
Engine oil	
Changing oil	100
Checking oil level and adding oil	98
Oil filler cap/dipstick	28
Oil filter	100
Oil high temperature indicator lamp	20
Recommendations	99
Engine stop switch	14
Exhaust system	
Cleaning	37
Purging	132
F	
Flag pole bracket	30
Flooded engine	58
Fuel	
Fuel recommendations	86
Fuel strainer screen	88
Fuel fill cap	26, 84
Fuel tank cap vent lever	26
Fuel tank capacity	84
Fuel valve	26