

Helmet Holder/Steering Lock

The helmet holder also serves as the steering lock. To lock the steering and use the helmet holder:

1. Turn the handlebars all the way to the right and hang your helmet on the hook at the hinge.
2. Insert the key (1) into the steering lock (2) and turn the key all the way to the left.
3. Remove the key.

WARNING

- * *Do not engage the steering lock while riding the TRX.*
- * *The helmet holder is designed for helmet security while parking. Do not operate the TRX with a helmet attached to the holder.*




- (1) Ignition key
(2) Helmet holder/steering lock

Storage Compartment/Owner's Manual Compartment

The storage compartment (1) is at the rear of rear fender. Pull the lever (2) up to open. The owner's manual compartment (3) is in the storage compartment.

This owner's manual should be stored in the compartment. When washing your TRX or riding through the water, be careful not to flood this area with water.



- (1) Storage compartment
(2) Lever
(3) Owner's manual compartment