

MAINTENANCE SCHEDULE

	FREQUENCY	ITEMS	Whichever comes first ⇒	INITIAL		REGULAR		Refer to page	
				NOTE	HOURS	MAINTENANCE INTERVAL			
						mi	600		1200
						km	150		1000
			20	100	200				
EMISSION RELATED ITEMS	*	FUEL LINE					I	—	
	*	THROTTLE OPERATION					I	104	
	*	CARBURETOR CHOKE					I	109	
		AIR CLEANER	(NOTE 1)			C	C	105 – 107	
		AIR CLEANER HOUSING DRAIN TUBE	(NOTE 2)			I	I	108	
		SPARK PLUG				I	I	118 – 119	
	*	VALVE CLEARANCE			I	I	I	119	
		ENGINE OIL			R	R	R	37, 112 – 116	
		ENGINE OIL FILTER			R	R	R	112 – 116	
	*	ENGINE IDLE SPEED			I	I	I	110	

I: Inspect and Clean, Adjust,
Lubricate or Replace if necessary.

C: Clean R: Replace

A: Adjust L: Lubricate