

T

Throttle	
Cable	104
Lever.....	20, 104
Tires	
Inflation and air pressure	140
Repairing.....	143
Specifications	141
Tread condition	142
Tool kit	99
Trailer hitch	40
Trailer towing	
Operational guidelines.....	50
Weight limits.....	49
Transporting procedures.....	148
Tripmeter.....	28
Turning	
On level ground.....	78
On slopes	91

V

Valve clearance	121
-----------------------	-----

W

Warning labels	7
Warranty service.....	161
Water	
Draining from brakes	138
Riding through.....	93
Weight limits	49
Wheel removal.....	139
Wiring diagram	158