

Indicators & Displays

1	Reverse indicator	Lights when the transmission is in reverse. <i>Lamp Check</i>
2	Neutral indicator	Lights when the transmission is in neutral. <i>Lamp Check</i>
3	Oil high temperature indicator	Lights when engine oil temperature is high enough to adversely affect the service life of the engine. If the oil high temperature indicator comes on while you are riding, immediately bring the vehicle to a stop, turn the engine off and let it cool. See page 178. <i>Lamp Check</i>
(below Canada only)		
4	Multi-function display	The display includes the following functions. <i>Display Check.</i>
	Speedometer	Shows riding speed.
	Odometer	Shows accumulated mileage (page 18).
	Tripmeter	Shows mileage per trip (page 18).
	Hourmeter	Shows hours and tenths of hours of engine operation (page 19).
	Digital clock	Shows the time (hours and minutes) (page 20).
5	Minute select button	Advances the minutes displayed by the digital clock (page 20).
6	Hour select button	Advances the hour displayed by the digital clock (page 20).
7	Hourmeter/digital clock select button	Selects display of the hourmeter or digital clock (pages 19 , 20).
8	Odometer/tripmeter select button	Selects display of the odometer or tripmeter. Resets the tripmeter to zero (0) (page 18).