


# Controls & Features

---

## Accessory Socket

### LEFT FRONT FENDER



- (1) accessory socket  
(2) front fender

- (3) cap

The accessory socket (1) is attached to the left side of the front fender (2). You can use the accessory socket to power a trouble light, spotlight, CB radio, or cell phone, etc.

### NOTICE

*Do not plug in any heat-generating accessory such as an automobile cigarette lighter because it can damage the socket.*

To use the accessory socket, turn the ignition switch ON (I) to start the engine. Then turn the headlights OFF, and open the accessory socket cap (3).