

Maintenance Schedule

Maintenance Procedures:

I: inspect and clean, adjust, lubricate, or replace, if necessary

C: clean

A: adjust

L: lubricate

R: replace

ITEMS	FREQUENCY	WHICHEVER COMES FIRST		INITIAL MAINT.	REGULAR MAINT. INTERVAL		Refer to page
		mi	km	100	600	1200	
				150	1000	2000	
		NOTE	HOURS	20	100	200	
* FUEL LINE					I		—
* THROTTLE OPERATION					I		117
* CARBURETOR CHOKE					I		119
AIR CLEANER	NOTE 1				C	C	112
AIR CLEANER HOUSING DRAIN TUBE	NOTE 2				I	I	116
SPARK PLUG					I	I	123
* VALVE CLEARANCE				I	I	I	126
ENGINE OIL				R	R	R	103
ENGINE OIL FILTER				R	R	R	107
* ENGINE IDLE SPEED				I	I	I	122

* Should be serviced by your Honda dealer, unless you have the proper tools and service data and are mechanically qualified. Refer to the official Honda Service Manual (page 202).