

Table of Contents

Chassis

| | |
|---------------------------------|-----|
| Brakes..... | 128 |
| Tires | 141 |
| Engine Guard & Skid Plates..... | 148 |

Electrical

| | |
|--------------|-----|
| Battery..... | 149 |
|--------------|-----|

| | |
|-----------------------|-----|
| Appearance Care | 154 |
|-----------------------|-----|

TIPS..... 159

| | |
|---------------------------------------|-----|
| Preparing for a Ride | 160 |
| What to Take to the Riding Area | 160 |
| What to Take on the Trail | 161 |
| Transporting Your Honda | 162 |
| Storing Your Honda | 164 |
| Preparation for Storage | 165 |
| Removal from Storage | 167 |
| You & the Environment..... | 168 |

TAKING CARE OF THE UNEXPECTED..... 169

| | |
|--|-----|
| General Guidelines..... | 170 |
| If Your Engine Quits or Won't Start..... | 172 |
| If You Have a Flat Tire | 175 |
| If the Oil High Temperature Indicator Lights | 178 |
| If a Fuse Blows | 179 |
| If You Crash..... | 183 |
| If You Lose Your Key | 184 |
| If a Component Fails..... | 185 |